

Ambor Tower Un-Nesting Guide



Tower Un-nesting:

1. To assist with tower un-nesting, you can use a forklift, a truck hitch or 3-ton come-along. Each bundle of nested towers should have a metal wire attached to the drain holes or the flange at the end of the section. During shipment, this wire is used to secure the sections from moving. This wire can be re-used to help pull out the inside sections.
2. Make sure the wire is attached to the inner most section.
3. Attach a strap or rope to the metal wire and then to the equipment. If you are using the 3-ton come-along, make sure it is fixed to a secure point.
4. Slowly back the vehicle straight away from the tower sections or begin to use the lever on the come-along to increase tension on the strap. The inside shaft section should begin to slide out.
5. Once the shaft section is out of the larger section, remove the wire and move the section out of the way.
6. Attach the wire to the next section and repeat this process until all sections have been un-nested.
7. In some cases, an additional steel cable will be provided with the tower bundle to help with the un-nesting. This steel cable can be used in the same way as the metal wire. Complete steps 3-6 with the steel cable is provided.

